

AVC ASIA VITAL COMPONENTS CO.,LT

A117 GPU Thermal Module Assembly Generic MTD

Rev 09: 05/29/2018

Update:2018/5/29

Rev. 02

Update in Blue

MTD Revision History

Update Date	Drawing Rev	MTD Rev	Update Description	DRI	
03/05/18	730-00127-06	06			
03/21/18	6re 0.1		Fin zipper modified;FAI 11 nominal reduced 0.70,FAI 6reassigned;FAI 7-9 removed ;FAI 10 tolerance incereased 0.1;FAI 15 removed ;FAI14 datums changed ;FAI 14,16 moved to clarify		
03/30/18	730-00127-08	08	Datums B and C moved to inner stand offs,outer inserts height reouced to flush;ad just ments to fin count and pitch affecting vc profile;		
04/04/18			Updated fin radius reassigning FAI 4,fill tube length max increased from 6.5 to 8.5		
_					

Note: Please always check and use the latest MCO revision for all spec.

Update in Blue


Piece part summary

SPC	FAI	Specification	Description	Part State	In-Process	FAI/Cpk
SPC dimension on the drawing	FAI dimension on the drawing	Nominal +/- Tolerance	Description of dimension being measured Ex. Side flatness	Free /Constrained ?	In-process measurement gage used	Measurement equipment for FAI/Cpk reporting
	FAI 1	8.0 mm Max	长度		-	ОММ
	FAI 3	262.00+/- 0.50 mm	总长度		-	СММ
	FAI 4	R3.90+/- 0.10mm	圆角		-	ОММ
	FAI 5	1.80+/- 0.10 mm	底高度		-	Height Gauge
	FAI 10	140.1 +/- 0.4mm	总宽度		-	СММ
	FAI 11	4x0.000+0.000/- 0.200mm	高度x 4		-	Height Gauge
SPC I	FAI 12	4x0 .000+/- 0.100mm	高度x 4		-	ОММ
SPC E	FAI 13	70.50+/-0.30 mm	轮廓度		-	СММ
	FAI 14	1.0 mm Max	面轮廓度		-	СММ
	FAI 16	0.50 mm Max	面轮廓度		-	СММ
SPC F	FAI 17	4x0.35 mm Max	位置度		-	СММ
SPC G	FAI 18	4x0.35 mm Max	位置度		-	СММ
	FAI 20	1.00 mm Max	面轮廓度		-	СММ
SPC B	FAI 21	0.26 mm Max	平面度		-	СММ
SPC A	FAI 22	0.10 mm Max	平面度		-	СММ

Equipment Information



Brand:	HEXAGON	
Type:	Global performance07.10.07	
Range:	X=700 mm Y= 1000 mm Z= 1000 mm	
Precision:	XYZ = (1.5 + 3L/1000)micron	
	Z = (1.2 + 5L/1000)micron	



Brand:	Mitutoyo
Type:	QV606
Range:	X=600 mm Y= 650 mm Z= 250 mm
Precision:	XYZ = (2.2 + 3L/1000)micron
	Z = (4 + 5L/1000)micron

Equipment Information




Brand:	Mitutoyo
Type:	543-461B
Range:	0~50mm
Accuracy:	0.001mm

Measurement Method

Update in Blue

SPC A	FAI 22	0.1 mm Max	СММ
SPC F	FAI 17	0.35 mm Max	СММ
SPC G	FAI 18	0.35 mm Max	СММ

- 1.以上尺寸测试设备均为三次元.
- 2.在凸台面上4个圆角与中心取5个点构成基准面A.
- 3.在螺柱内取8点构造圆1并设为基准原点B
- 4. 在另一螺柱内取8点构造圆2,圆1与圆2构造直线1且圆2偏置64mm并设为基准轴.
- 5. 在凸台面上4表圆角与中心取5点构造平面即可计算其平面度(SPC A)
- 6.在螺柱内取8点构造圆并输入对应的理论值,通过基准即可计算其位置度(SPCF)余下三个螺柱皆按此方法
- 7.在螺纹孔内取8点构造圆并输入对应的理论值,通过基准即可计算其位置度(SPCG)余下三个螺纹孔皆按此方法




Measurement Method

Update in Blue

SPC B	FAI 21	0.26mm Max	CMM


- 1.以上尺寸测试设备为三次元.
- 2. 将样品放在固定柱上,保证不会晃动
- 3.在样品上取8点(以外形4個R角的圓心取4個點;2,中間4個點如下圖,不能太靠近BOSS柱邊緣)构造平面即可计算其平面度。




Measurement Method

SPC E	FAI 13	70.5+/-0.3 mm	СММ

- 1.以上尺寸测试设备为投影仪.
- 2. 在标准块上均匀取6点构造平面且把Z归零 3.将样品放在标准块上,在凸台面中心取一点即可算出其高度






Measurement Method

SPC I	FAI 12	0+/-0.1mm	ОММ

- 1.以上尺寸测试设备为投影仪.
- 2.在凸台面上取五点且将Z归零.
- 3在螺柱上取圆1,圆2.圆1设为原点且与圆2构造直线作轴.
- 4在每个螺柱上取3点,取每个螺柱上的最高值



THANK YOU THERMAL SOLUTIONS FOR YOUR NEEDS

AVC Confidential